

4V100-400 Series Baseplate



Baseplate Ordering Code



100M

-

□F

Series Code

100M: Baseplate for 100 Series Use
200M: Baseplate for 200 Series Use
300M: Baseplate for 300 Series Use
400M: Baseplate for 400 Series Use

Joint Base Number

100M: 1~20F
200M: 1~20F
300M: 1~20F
400M: 1~20F

Blindplate Ordering Code

200M

-

B

Series Code

For 100 Series Use
For 200 Series Use
For 300 Series Use
For 400 Series Use

Blind Plate Code

B: Blanding plate
C: Sealing gasket
D: Screw